



ACCESSORY MOUNT CLAMP KIT

Contains 1 Pair of Modified Cateye Clamps

Note: shims are for adjusting fit and are not needed to protect paint

- | | |
|------------------------|-------------------------|
| ○ 1/2" BS-3, Full Shim | ○ 1" SP-5, No Shim |
| ○ 5/8" BS-5, 3/4 Shim | ○ 1-1/8" SP-6, No Shim |
| ○ 3/4" HP-5, Full Shim | ○ 1-1/4" SP-8, 3/4 Shim |
| ○ 7/8" HP-5, No Shim | |

Inserted Spacer: ○ 0.35" ○ 0.5"



info@t-cycle.com

5726 SE Center St. Portland, OR 97206 USA



Fine tune the Cateye Clamp fit by trimming the length of the shims to make the gap about 1/8in (3mm) and the outer ears parallel. Zero to 100% of the shim may be required depending on your application. See chart on other side for typical amounts of shim needed.

