

Bar End Shifter Micro Mount MicroSHIFT Version



○ Long (30mm) ○ Short (15mm)

Installation Instructions

Installing the Bar End Shifter Micro Mount on a microSHIFT shifter is a simple process. That said, if you are unfamiliar with shifters or are uncomfortable taking them apart and putting them back together, we recommend asking for help from a local bike shop.

Tools Required

All you'll need is a 4mm Allen wrench.

Assembly

Installation happens in four steps: slack the cable, remove the special inside nut, insert the Bar End Shifter Micro Mount, and retighten the stock bolt.

1. Slack the shifter cable completely by shifting to the smallest cog/chainring.

2. Loosen the bolt on the outside of the shifter completely without removing it. Be sure to hold the shifter together while you do this. Push on the bolt to slide the special inside nut out the other side of the shifter assembly. Put the special nut somewhere for safe keeping.

3. Insert the tower of the Bar End Shifter Micro Mount into the opening where the special microSHIFT inside nut was. The tower is an exact replacement for it.

4. Reinsert and tighten the stock bolt back into place and you're ready to ride!

Bar End Shifter Micro Mount MicroSHIFT Version



○ Long (30mm) ○ Short (15mm)

Installation Instructions

Installing the Bar End Shifter Micro Mount on a microSHIFT shifter is a simple process. That said, if you are unfamiliar with shifters or are uncomfortable taking them apart and putting them back together, we recommend asking for help from a local bike shop.

Tools Required

All you'll need is a 4mm Allen wrench.

Assembly

Installation happens in four steps: slack the cable, remove the special inside nut, insert the Bar End Shifter Micro Mount, and retighten the stock bolt.

1. Slack the shifter cable completely by shifting to the smallest cog/chainring.

2. Loosen the bolt on the outside of the shifter completely without removing it. Be sure to hold the shifter together while you do this. Push on the bolt to slide the special inside nut out the other side of the shifter assembly. Put the special nut somewhere for safe keeping.

3. Insert the tower of the Bar End Shifter Micro Mount into the opening where the special microSHIFT inside nut was. The tower is an exact replacement for it.

4. Reinsert and tighten the stock bolt back into place and you're ready to ride!