

Bar End Shifter Micro Mount

SRAM Version



Long (30mm)

Short (15mm)

Installation Instructions

Installing the Bar End Shifter Micro Mount on a SRAM shifter is straightforward but requires specific torque and knowledge of the different bolts of the SRAM shifter. If you are unfamiliar with shifters or are uncomfortable taking them apart and putting them back together, we recommend asking for help from a local bike shop.

Tools Required

You'll need a 4mm Allen, and preferably, a torque wrench.

Assembly

Installation happens in four steps: slack the cable, remove the housing bolt, insert the Bar End Shifter Micro Mount, and screw in the provided replacement bolt.

- 1. Slack the shifter cable** completely by shifting to the smallest cog/chainring.
- 2. Identify the Housing Bolt.** There are two bolts to a SRAM shifter: the Housing Bolt (on the arm coming up from the base of the shifter) and the friction bolt (in a cap on the lever side). DO NOT attempt to install the Bar End Shifter Micro Mount onto the Friction Bolt side. It won't work.
- 3. Remove the Housing Bolt** using the 4mm Allen wrench, and store the bolt away for safe keeping.
- 4. Use the included m6x14 button head bolt to attach the Bar End Shifter Micro Mount** into the opening where the stock bolt was.
- 5. Torque the bolt to 5Nm (firmly tight).** Now you're ready to ride!

Bar End Shifter Micro Mount

SRAM Version



Long (30mm)

Short (15mm)

Installation Instructions

Installing the Bar End Shifter Micro Mount on a SRAM shifter is straightforward but requires specific torque and knowledge of the different bolts of the SRAM shifter. If you are unfamiliar with shifters or are uncomfortable taking them apart and putting them back together, we recommend asking for help from a local bike shop.

Tools Required

You'll need a 4mm Allen, and preferably, a torque wrench.

Assembly

Installation happens in four steps: slack the cable, remove the housing bolt, insert the Bar End Shifter Micro Mount, and screw in the provided replacement bolt.

- 1. Slack the shifter cable** completely by shifting to the smallest cog/chainring.
- 2. Identify the Housing Bolt.** There are two bolts to a SRAM shifter: the Housing Bolt (on the arm coming up from the base of the shifter) and the friction bolt (in a cap on the lever side). DO NOT attempt to install the Bar End Shifter Micro Mount onto the Friction Bolt side. It won't work.
- 3. Remove the Housing Bolt** using the 4mm Allen wrench, and store the bolt away for safe keeping.
- 4. Use the included m6x14 button head bolt to attach the Bar End Shifter Micro Mount** into the opening where the stock bolt was.
- 5. Torque the bolt to 5Nm (firmly tight).** Now you're ready to ride!