

## Bar End Shifter Micro Mount Shimano Version



Long (30mm)

Short (15mm)

### Installation Instructions

Installing the Bar End Shifter Micro Mount on a Shimano shifter is a simple process. That said, if you are unfamiliar with shifters or are uncomfortable taking them apart and putting them back together, we recommend asking for help from a local bike shop.

### Tools Required

All you'll need is a flathead screwdriver.

### Assembly

Installation happens in four steps: slack the chain, remove the special Shimano inside nut, insert the Bar End Shifter Micro Mount, and retighten the stock bolt.

- 1. Slack the shifter cable** completely by shifting to the smallest cog/chainring.
- 2. Loosen the bolt** on the outside of the shifter completely **without removing it**. Be sure to **hold the shifter together** while you do this. Push on the bolt to slide the special inside nut out the other side of the shifter assembly. Put the special nut somewhere for safe keeping.
- 3. Insert the tower of the Bar End Shifter Micro Mount** into the opening where the special Shimano-inside nut was. The tower is an exact replacement for it.
- 4. Reinsert and tighten the stock bolt** back into place and you're ready to ride!

## Bar End Shifter Micro Mount Shimano Version



Long (30mm)

Short (15mm)

### Installation Instructions

Installing the Bar End Shifter Micro Mount on a Shimano shifter is a simple process. That said, if you are unfamiliar with shifters or are uncomfortable taking them apart and putting them back together, we recommend asking for help from a local bike shop.

### Tools Required

All you'll need is a flathead screwdriver.

### Assembly

Installation happens in four steps: slack the chain, remove the special Shimano inside nut, insert the Bar End Shifter Micro Mount, and retighten the stock bolt.

- 1. Slack the shifter cable** completely by shifting to the smallest cog/chainring.
- 2. Loosen the bolt** on the outside of the shifter completely **without removing it**. Be sure to **hold the shifter together** while you do this. Push on the bolt to slide the special inside nut out the other side of the shifter assembly. Put the special nut somewhere for safe keeping.
- 3. Insert the tower of the Bar End Shifter Micro Mount** into the opening where the special Shimano-inside nut was. The tower is an exact replacement for it.
- 4. Reinsert and tighten the stock bolt** back into place and you're ready to ride!