



# TerraCycle

Recumbent Cycling Essentials

## Trike Tight Table Top Work Stand

Assembly & Instructions



### Introduction

The TrikeTight Table Top Workstand is a great way to work on your trike without compromising comfort!

### Tools Required

You will only need a 4mm Allen (hex) wrench.

### Assembly

**1. You have already pulled the PARTS BAGGY** from the box, since that is where this piece of paper was packed. There should be three bungees, three washers, three M6x45 bolts, and three M6x60 bolts with washers screwed into 2-flanged knobs.



Contents of PARTS BAGGY

**2. Pull the T-ASSEMBLY** from the box. Remove the lock pin from the plate, unfold the assembly until the tubes are perpendicular to one another, and replace the lock pin to secure the T-ASSEMBLY in this orientation.



T-ASSEMBLY

**3. Install each LEG** onto the T-Shaped Plate at the end of the T-ASSEMBLY by loosely screwing one 45mm bolt into the lower hole of the T-ASSEMBLY plate and through the lower hole of the LEG. Then, thread the 60mm bolt (the one with the knob) through the T-ASSEMBLY plate and through the upper hole of the LEG, using the 2-flanged knob as a nut on the far side.



LEGS

CRADLES

**4. Install each CRADLE** into the T-ASSEMBLY. Place one 3-Flanged Knob onto each CRADLE, followed by a 3/8in ID washer. Then screw the cradle into the UPRIGHT tube. The cradles can be screwed outward and inward to dial in the height, just use the knob on the bottom of the threaded shaft to lock the cradle in place.

**5. With everything in place, tighten all the bolts.** Tighten them enough that everything is secure, but make sure the LEGS can swing as necessary, and that the T-ASSEMBLY can fold when the lock pin is removed. Note that the swing of the LEGS will help when assessing the right fit for your trike.

**6. Finally, pull the bungees** from the PARTS BAGGY. The bungees hook onto one end of the cradle, across the tubing of your trike, and onto the other end of the cradle. This keeps your trike from tipping about when set in the work stand.



BUNGEE



## Stowing the Stand

Pull the **LOCK PIN** from the plate of the T-ASSEMBLY and fold the stand until the lock pin can be reinserted through the plate and into the center tube to secure it in a folded position.

