



ACCESSORY MOUNTS

ADJUSTOMATIC BOTTLE HOLDER



INSTALLATION AND ASSEMBLY

This Adjustomatic Bottle Holder is designed to hold one or two standard bottle cages and can attach to any standard bottle holder mounts on your bike or trike. Adjustable to hold your bottles at any angle from 45 to 90 degrees, it's designed to be reversible so you can angle your bottles forward or back. Installation involves choosing your forward or backward angle, mounting the Bottle Holder, adjusting the angle, and installing the bottle cages. Let's get started!

Tools Required

3mm Allen wrench
4mm Allen wrench



1. Choose Angle

Slightly loosen the angle adjustment screw so the tower can move. Position the holder base in place on your bike/trike's mounts. Decide whether you'd like the bottles to angle forward or angle back. Turn the Bottle Holder forward or back accordingly.


ANGLING TIPS

If your seat is close to the bottle mounts on the frame, position *more forward*.

If your seat far from the bottle mounts on the frame, position *more backwards*.


2. Attach the Bottle Holder

This is most easily done with the tower at 90 degrees so you have room on both sides for the Allen wrench. Use the m5x12 (longer) bolts to attach the holder to your frame. Tighten the bolts securely, about 2.5 ft-lbs (3.5 N-m).



3. Attach the Cages

There are three pairs of holes for mounting bottle cages: High, Medium, and Low. If the tower is angled down, the cage on the inside (acute side) will need to be higher on the tower so the bottle won't bump on the frame. The cage on the outside (obtuse side) can use either remaining pair of holes. Attach the cages with the m5x10 (shorter) bolts. Tighten the bolts securely, about 2.5 ft-lbs (3.5 N-m).



4. Test Out and Adjust as Needed

Sit in your seat and test out your new bottle holder! Make sure it's not in the way of you getting in and out. When you're happy with the placement, tighten the angle adjusting screw securely (about 2.5 ft-lbs or 3.5 N-m). You can also use the 3 holes in the other side, which are at 45, 67.5, and 90 degrees.

Switch it up! You can swap out the bottle cage to mount other accessories!

THAT'S IT! ENJOY!



Adjustomatic Bottle Holder Assembly Instructions V2.1 2025
TerraCycle, Inc. 5726 SE Center St. Portland, OR 97206 USA info@t-cycle.com



Adjustomatic Bottle Holder Assembly Instructions V2.1 2025
TerraCycle, Inc. 5726 SE Center St. Portland, OR 97206 USA info@t-cycle.com

